

Automation System TROVIS 6400 Industrial Controller TROVIS 6497

SAMSON



Mounting and Operating Instructions

EB 6497 EN

Firmware version 1.1.x
Edition August 2004

Contents

1	Description	4
1.1	Versions	4
1.2	Technical data	5
2	Installing the industrial controllers	6
2.1	Opening the controller case	6
2.2	Fuses	7
2.3	Jumpers to switchover between WE, Y and AA	7
2.4	Converting the controller to 120 V power supply	7
3	Electrical connections	8
4	Operation	10
4.1	Process display and control panel elements	10
4.2	OPERATING level	12
	<i>X</i> <i>D</i> Error	12
	<i>W</i> <i>I</i> Internal setpoint	12
	<i>W</i> <i>E</i> External setpoint	12
	<i>Y</i> Manipulated variable	12
	<i>X</i> Controlled variable	12
4.3	PARAMETER level	13
	Accessing the PARAMETER level	13
	Entering and modifying parameter values	13
	Exiting the PARAMETER level	13
	<i>K</i> <i>P</i> Proportional-action coefficient	13
	<i>T</i> <i>N</i> Reset time	13
	<i>T</i> <i>V</i> Rate time	14
	<i>K</i> <i>D</i> Rate gain	14
	<i>W</i> <i>R</i> Operating direction	14
	<i>Y</i> <i>L</i> , <i>Y</i> <i>H</i> Manipulated variable limits	14
	<i>Y</i> <i>O</i> Operating point	14
	<i>L</i> <i>R</i> Limit value or transfer coefficient for Y1	14
	<i>L</i> <i>H</i> Hysteresis or minimum pulse duration for Y1	14
	<i>L</i> <i>R</i> Limit value or transfer coefficient for Y2	15
	<i>L</i> <i>H</i> Hysteresis or minimum pulse duration for Y2	15
	<i>T</i> <i>I</i> Switching time	15
	<i>T</i> <i>Z</i> Switching time	15
	<i>T</i> <i>Z</i> Dead band	15
	<i>L</i> <i>R</i> Limit value for GW3	15
	<i>L</i> <i>H</i> Hysteresis for GW3	15
	<i>L</i> <i>R</i> Limit value for GW4	15
	<i>L</i> <i>H</i> Hysteresis for GW4	15
4.4	CONFIGURATION level	16
	Accessing the CONFIGURATION level	16
	Determining and modifying values of the configuration blocks	16
	Exiting the CONFIGURATION level	16
	<i>X</i> <i>N</i> and <i>X</i> <i>E</i> Measuring range limits of the controlled variable X	17
	<i>X</i> <i>.</i> Decimal points	17

	∞M	Selecting the input signal	17
	∞T	Unit of temperature	17
	∞*	Range of current or voltage signal for X	17
	∞*	Range of current or voltage signal for WE	18
	∞*	Range of current or voltage signal for Y and AA	18
	DI	Selecting the input circuitry of the derivative-action component	18
	WM	Selecting the setpoint	18
	YH	Blocking the MANUAL/AUTOMATIC mode selector key	18
	YM	Selecting the controller output	19
	YR	External position feedback	19
	1M and 2M	Signaling condition of the limit values	19
	51 and 52	Switching outputs Y1 or Y2 as NO or NC contacts	19
	3M and 4M	Signaling condition of the limit values	20
	53 and 54	Limit switches GW3 and GW4 as NO or NC contacts	20
	TR	Update cycle to refresh display of controlled variable	20
	FI	Digital filter	20
	K1	Safety output value	20
	C1 and C2	code numbers	21
		Service code number	21
	SD	Auto-tuning	21
	TS	Setpoint ramp	22
	SN	Station address	22
	BR	Baud rate	22
5		Standard controller outputs	23
5.1		Continuous-action controller	23
5.2		Switching outputs Y1 and Y2	23
5.3		Three-point stepping controller with internal position feedback	26
5.4		Three-point stepping controller with external position feedback	27
5.5		Pulse-modulated control outputs	29
6		Serial interface	31
6.1		Description	31
6.2		Technical data	31
6.3		Operation	32
6.4		Value registers (holding registers)	33
6.5		Status register	34
7		Start-up	35
7.1		Tuning control parameters	36
7.2		Auto-tuning	38
8		Check list	40
9		Control panel	44

Changes in Firmware version 1.10

The parameter default settings of TN and operating direction have been changed.

1 Description

The TROVIS 6497 Industrial Controller is used to automate industrial and processing plants. Through the use of a practical, clearly structured functional design, various control circuit arrangements can be configured. It may be used as a continuous-action controller, on-off or three-point stepping controller with the following control mode options: P, PI, PD or PID modes.

A sealed membrane operator panel is used to operate the industrial controller. Operation is divided into three simple logical levels: OPERATING level, PARAMETER level and CONFIGURATION level.

Accessing the OPERATING level via displays for standard control operation is possible at any time. User-selectable code numbers must be entered in order to access the PARAMETER and CONFIGURATION levels. In the PARAMETER level, control parameters can be modified and optimally tuned specifically to the process. In the CONFIGURATION level, various controller functions can be selected.

The controller accepts the following universal inputs: Pt 100 resistance thermometers, thermocouples, standardized current and voltage signals as well as two-wire transmitters.

The controller's setpoint can be switched between the internal $W I$ setpoint and external $W E$ setpoint (reference variable) by means of the WE/WI setpoint switchover key or over a binary signal). Moreover, the setpoints can be selected and interconnected.

Bumpless transfer in the respective operating mode is made using the MANUAL/AUTOMATIC mode selector key.

Essential control parameters can be automatically determined and selected by the program using special auto-tuning software feature.

1.1 Versions

TROVIS

6497-03

Output

Continuous-action/on-off/three-step/analog output, limit switches

Input

Two temperature ranges are available for measuring temperature with three-wire **Pt 100 resistance thermometers**:

- ▶ Version 1: -100 °C to +400 °C in 1 °C steps
- ▶ Version 2: - 30.0 °C to +150.0 °C in 0.1 °C steps

The valid temperature range is printed on the nameplate next to PT 100.

Options

- ▶ Two additional limit switches
- ▶ RS-485 serial interface with Modbus RTU software

This manual applies to controllers implementing firmware version 1.10 (see page 36)



Caution!

This controller may only be assembled, started up and operated by trained personnel familiar with such technical procedures.

1.2 Technical data

Inputs	Controlled variable X		
	Direct current signal	4 (0) to 20 mA	$R_i = 2.5 \Omega$
	DC voltage signal	0 (2) to 10 V	$R_i > 100 \text{ k}\Omega$
	Pt 100 potentiometer, self-calibrating (three-wire circuit)		
	Version 1	-100 to +400 °C	Resolution 1 °C
	Version 2	-30.0 to +150.0 °C	Resolution 0.1 °C
Thermocouples (requires reference junction module, order no. 1600-1269)			
Type K: NiCr-Ni	50 to +1200 °C	DIN IEC 584	
Type S: Pt10Rh-Pt	50 to +1700 °C	DIN IEC 584	
Type L: Fe-CuNi	50 to + 800 °C	DIN 43 710	
Type U: Cu-CuNi	50 to + 600 °C	DIN 43 710	
External position feedback YR			
Potentiometer 0 to (200 to 1000) Ω in two-wire circuit , measuring current with 1000 Ω potentiometer approx. 2.7 mA; with 200 Ω potentiometer approx. 13 mA or			
Direct current signal 4 to 20 mA (with shunt resistance 549 Ω , 0.5 W; 1 %)			
External setpoint WE			
4 (0) to 20 mA or 0 (2) to 10 V selectable over jumpers			
External setpoint switchover			
Binary input switchover between WE/WI with 24 V DC			
Signal 0 V → internal WI; 24 V → external WE (select over WI) or external restart of the setpoint ramp			
Transmitter supply voltage: 24 V DC / max. 30 mA			
Outputs	Control output signal Y (selectable over jumpers)		
	Current	-20, 4 (0) to 20 mA,	Load $R_B < 500 \Omega$ or
	Voltage	-10, 0 (2) to 10 V,	Load $R_B > 500 \Omega$
	Analog output AA: 0 (4) to 20 mA / 0 (2) to 10 V		
Switching outputs Y1 and Y2			
(Optional: 2 limit switches GW3 and GW4)			
Load rating of switching contacts max. 250 V AC / 1 A with $\cos \varphi = 1$			
Hysteresis (minimum) 0.3 %			
Power supply	230 V AC, 48 to 62 Hz · 120 V AC, 48 to 62 Hz		
	Optional: 24 V AC, 48 to 62 Hz		
Power failure	All parameter values and configuration blocks are internally stored against power failure in a non-volatile EEPROM		
Power consumption	10 VA		
Permissible temperature	Ambient 0 to 50 °C · Transportation and storage 0 to 70 °C		
Measuring error	Linearity	Zero point	Final value
	mA, V, Pt 100	0.2 %	0.2 %
	Thermocouple	0.2 %	0.3 %
Degree of protection	IP 54 (front panel), IP 20 (case)		
VDE 0110 Part 1	Overvoltage category II · Degree of contamination 2		
Electromagnetic compatibility	Requirement stipulated in EN 61000-6-2, EN 61000-6-3 are fulfilled.		
Weight	0.8 kg		

2 Installing the industrial controllers

The industrial controller is designed for panel mounting. Its front case has the dimensions 96 mm x 96 mm. Mount the controller as follows:

1. Prepare a panel cut-out with the dimensions $92^{+0.8} \times 92^{+0.8}$ mm.
2. Push the industrial controller into the panel cut-out from the front side.
3. Insert the two supplied mounting brackets in either the left and right (or top and bottom) openings provided in the case (see Fig. 1).
4. Turn the threaded rods in the direction of the control panel using a screwdriver, clamping the front frame of the case against the control panel.




Fig. 1 - Dimensions of the controller case

2.1 Opening the controller case

To exchange the fuse or for re-jumpering (see sections 2.2 to 2.4), the case must first be opened as follows:

1. Remove terminals, unloosen threaded rods and lift off mounting brackets. Then, pull the industrial controller out of the control panel and force off the front panel.
2. Unscrew the two screws at the side, and press the two transparent nipples down towards the front using a suitable screwdriver or appropriate tool.
3. Remove the controller section from the front after lightly tapping the terminal blocks.
4. Replace the fuses and/or re-jumper as required (see sections 2.2 to 2.4).
5. Subsequently, re-install the controller section, fasten the two screws and assemble the front panel. Proceed as instructed in section 2, steps 2 to 4.




Fig. 2 - Arrangement of microprocessor boards in the controller unit

2.2 Fuses

The power supply board (see Fig. 2) contains an overload protection directly next to the terminal block. For the 230 V version, use TR 5 (63 mA) with the order number: 8834-0343; for the 120 V version, use TR 5 (125 mA), order number: 8834-0346.

To open the case, see section 2.1.

2.3 Jumpers to switchover between WE, Y and AA

The external setpoint WE, manipulated variable Y and analog recorder connection AA can be wired as either mA or V signals, whereby mA is the factory default. These signals can be modified by jumpering the I/O board accordingly (see Fig. 2). Refer to the jumper locations depicted in Fig. 3.

To open the case, see section 2.1.




Fig. 3 · Jumper locations

2.4 Converting the controller to 120 V power supply

The controller can be converted from the power supply 230 V to 120 V. To proceed, make the following changes on the soldering side of the power supply board (see Fig. 2):

1. Open soldering jumper "230 V".
2. Close soldering jumpers "120 V 1" and "120 V 2".
3. Replace fuse TR 5 (63 mA) with fuse TR 5 (125 mA) (see also section 2.2).

3 Electrical connections

Plug-in, modular terminals are provided for the wires with cross sections from 0.5 to 1.5 mm². Always observe the pertinent VDE 0100 regulations and those regulations and guidelines valid in the country where the controller is intended to be installed.

Installation notes:

The signal and sensor lines are to be wired separately from the leads of the controller and power supply.

Use shielded signal and sensor lines to avoid measuring errors associated with radio interference. Always ground the shielded electrical lines on the side of the industrial controller.

Separately install the power supply lines and protective conductors of each industrial controller at the corresponding distributing bar. Protective circuits located in the vicinity must be suppressed against interference by means of a resistor-capacitor (RC) combination.




Fig. 4 · Terminal assignments

4 Operation

Unfold the last page of this manual (showing the control panel) to obtain a better understanding of this description when reading the following sections.

The industrial controller is designed with a three-level operating structure: OPERATING level, PARAMETER level and CONFIGURATION level. Depending on the selected level (mode), the keys and visual displays assume various functions.

The controller should always be configured (CO level) first, then the parameters selected (PA level) and finally tuned.

Section 5 on page 23 clearly describes how the industrial controller is to be tuned to both the control application and the directly controlled system.

4.1 Process display and control panel elements

1 Controlled variable (actual value) display

OPERATING level: Display of controlled variable x

 **Display upon breakage of sensor line:** If a sensor break is determined at the  input of the industrial controller or if the input range is exceeded in either direction, an  (over) or  (under) appear on the display. In this case, the manipulated variable is automatically adjusted to the value predetermined in configuration block $K1$ (safety output value). The industrial controller operates in standard mode once the sensor break has been corrected.

PARAMETER and CONFIGURATION level: Display of the numerical value relating to the selected parameter or configuration block.

2 Manipulated variable (output value) display

OPERATING level: Display of manipulated variable y in %

(For values > 100 , an H appears on the display; for values < 0 , NE appears), or display of the external position feedback.

PARAMETER and CONFIGURATION level: Display of the designation associated with the selected parameter or configuration block.

Note!

If  is displayed here, the default calibration of the controller has been lost. If this error occurs, please return the device to SAMSON!

3 Error (w - x) display

The yellow LED indicates the controlled range with zero offset; the two red LEDs indicate the error (designated as XD instead of e on the controller) for a deviation of at least $\pm 1\%$.

4 Switching output display

Two LEDs indicate the output state of the on-off/three-step control output or limit alarms.

5 Label for physical unit (of temperature)

Specification of the engineering unit applicable for the controlled variable display (1).

6 Cursor keys

Δ Increase displayed value

∇ Decrease displayed value

OPERATING level: After selecting WI : direct change of the setpoint.

In MANUAL mode (see MANUAL/AUTOMATIC mode selector key): direct adjustment of manipulated variable signal Y

PARAMETER and CONFIGURATION level: Selection of a single parameter or configuration block (lower display in (2)), selection of the associated values (upper display in (1))

7 Operating key

OPERATING level: Selection of certain controller variables (see page 12).

PARAMETER level: Return to the OPERATING level and AUTOMATIC mode*

CONFIGURATION level: Return to the OPERATING level and MANUAL mode*

* When manipulated variable display (2) flashes, first press the yellow ENTER key (8)!

8 ENTER key

OPERATING level: Call up the PARAMETER level PR and CONFIGURATION level CF ; confirm the entered code number, and enter the selected level.

PARAMETER/CONFIGURATION level: Call up the displayed parameter or configuration block (flashing in the lower display field (2) indicates that values can be modified); enter and confirm the value displayed in the upper field (1)

9 WE/WI (external/internal setpoint) switchover key

Selection of the external and internal setpoint. When the external setpoint WE is selected, the yellow LED in the key illuminates.

Switching to an external setpoint can also be made by applying an external 24 V DC signal (note configuration block $WI1$, see page 18).

10 MANUAL/AUTOMATIC mode selector key

Bumpless transfer from MANUAL to AUTOMATIC mode (or vice versa). MANUAL mode is indicated by a flashing yellow LED in the key.

In MANUAL mode, the manipulated variable Y can be modified using the cursor keys (6), thereby directly influencing the connected control valve.

4.2 OPERATING level



This is the standard operation mode of the industrial controller. The upper display field (1) indicates the actual value of controlled variable X ; the lower two-digit display field (2) indicates the current values (0 to 99 %) of the manipulated variable Y . If the manipulated variable drops below 0 %, NE will appear in the lower display field. If the manipulated variable exceeds 99 %, $H0$ to $H9$ for 100 % to 109 % will be displayed.

Press the operating key (7) to display the following variables in the lower display field (2). The associated values appear in the upper display field (1). Select \times return to standard operation mode.



\times **D Error**

($XD = W - X$)



W **I Internal setpoint (internal reference variable)**

The range of values depends on the measuring range limits $\times N$ and $\times E$ predetermined for controlled variable X .

Switch over to internal setpoint W I

Press the operating key (7) until W I appears in the lower display field (2).

Modify the value to the desired value indicated in the upper display field (1) by pressing the cursor keys Δ and ∇ .

Press the operating key (7); the value is stored insusceptible to power failure.



W **E External setpoint (external reference variable)**

A value is displayed under the condition that an external setpoint is connected.



Y **Manipulated variable (output variable)**

The range of values is represented as a percentage and depends on the manipulated variable limits determined with $Y \angle$ and $Y \rceil$ (see page 14).



\times **Controlled variable (actual value)**

This display only appears for approximately 4 seconds. Thereafter, controlled variable \times and manipulated variable Y are both subsequently displayed again.

The range of values in the display depends on the measuring range limits to be specified in the CONFIGURATION level with $\times N$ and \times (see page 17).

4.3 PARAMETER level



Control parameters can be selected in the PARAMETER level. Access is only possible after confirming the code number. The lower display field (2) indicates the parameter; the associated value is indicated in the upper display field (1).



Accessing the PARAMETER level

Press the ENTER key (8); PR appears in the lower display field (2). Press the ENTER key (8) again; the display PR flashes. Select the code number by pressing the cursor keys Δ and ∇ , see the upper display field (1). (Notes on code number, see page 21)

Re-press the ENTER key (8); the PARAMETER level is now opened. The first parameter KP (proportional-action coefficient) appears in the lower display field (2). The industrial controller returns to the OPERATING level upon entry of a wrong code number.

Entering and modifying parameter values

To access the PARAMETER level, see above.

Select the parameter using the cursor keys Δ and ∇ , see the lower display field (2).

Press the ENTER key (8); the selected parameter flashes.

Select the parameter value using the cursor keys Δ and ∇ (see the upper display field (1)) and accept by pressing the ENTER key (8).

Select the next parameter or exit the PARAMETER level; see below.

Exiting the PARAMETER level

Press the operating key (7) to return to the OPERATING level.

If the lower display field (2) flashes, first press the ENTER key (8)!

The following parameters can be selected in the PARAMETER level for the TROVIS 6487 Industrial Controller:



KP **Proportional-action coefficient** (P component of the controller)

Range of values 0.1 to 199.9



TN **Reset time** (integral-action component of the industrial controller)

Range of values 1 to 1999 s, disabled when set to 0

**2R Limit value or transfer coefficient for Y2**

For YM = 0 or 3 Limit value or switching point for Y2
 = 2 Transfer coefficient

**2H Hysteresis or minimum pulse duration for Y2**

For YM = 0 or 3 Hysteresis for Y2
 = 2 Minimum pulse duration in % of $T2$

**T1 Switching time**

For YM = 0 or 3 Period (cycle time) for pulse-modulated control outputs ($TM/2M = 8$ or 9)
 = 2 Period (cycle time) in positive oper. direction
 = 1 or 4 Transit time of associated actuator

**T2 Switching time**

For YM = 2 Period (cycle time) in negative oper. direction

**T3 Dead band**

Range of values 0 to 109.9% relating to the manipulated variable range
 The dead band (note definition!) is entered for three-point stepping control-
 lers with internal or external position feedback, the minimum pulse duration for
 pulse-modulated outputs and split point for pulse-modulated outputs
 with split-range.
 Refer to section 5 on page 23 for further details.

The following parameters only apply to versions with additional limit switches GW3 and GW4:

**3R Limit value for GW3**

The range of values depends on the configuration block $3M$.

**3H Hysteresis for GW3**

The range of values depends on the configuration block $3M$.

**4R Limit value for GW4**

The range of values depends on the configuration block $4M$.

**4H Hysteresis for GW4**

The range of values depends on the configuration block $4M$.

4.4 CONFIGURATION level



Functions linked to the required control task can be determined by the configuration blocks in the CONFIGURATION level. Access is only possible after confirming the code number.



The lower display field (2) indicates the configuration block; the upper display field (1) indicates the associated value. Configuration blocks can be selected and modified in the specified range.



Accessing the CONFIGURATION level

Press ENTER key (8); *PR* appears in the lower display field (2). Press cursor key Δ ; *00* appears in the lower display field (2).



Press the ENTER key (8); *00* flashes.

Enter the code number using the cursor keys Δ and ∇ ; see upper display field (1). (Notes on the code number, see page 21)

Re-press the ENTER key (8); the CONFIGURATION level is opened. The first configuration block *xN* appears in the lower display field (2). Upon entry of a wrong code number, the industrial controller returns to the OPERATING level.

Determining and modifying values of the configuration blocks

Open the CONFIGURATION level, see above.

Select the configuration block using the cursor keys Δ and ∇ .

Press the ENTER key (8); the selected configuration block flashes.

Select the desired value in the upper display field (1) using the cursor keys Δ and ∇ and store by pressing the ENTER key (8).

MANUAL mode is enabled the first time a value is modified.

Advance to the next configuration block using the cursor keys or exit the CONFIGURATION level, see below.

Exiting the CONFIGURATION level

Pressing the operating key (7) returns to the OPERATING level, whereby MANUAL mode is still activated. The manipulated variable y is switched to in the lower display field (2).

Press the MANUAL/AUTOMATIC mode selector key; the controller switches to AUTOMATIC mode.

The following configuration blocks determine the controller functions:



*N and *E Measuring range limits of the controlled variable X

These configuration blocks determine the initial value (*N) and end value (*E) of controlled variable X. They limit each other.



*M = 0, 3, Measuring range, see temperature range under *M; also
4, 5, 6 can be limited in respective range.

*M = 1, 2 Measuring range selectable between -1999 and +1999
with consideration of the decimal point *, .

The selected measuring range refers to an internal signal range from 4 to 20 mA (0 to 100 %); e.g., for a pressure transducer having a measuring range from 1 to 3 bar, select:

*N = 1.0 (i.e. = 4 mA or 0 %);

*E = 3.0 (i.e. = 20 mA or 100 %)



*P **Decimal points** (only for mA or V inputs, i.e. *M = 1 or 2)

The decimal point for the upper display field (1) can be defined between 0 and 3; e.g., 1000 (no decimal), 1.000 (three decimal places)



*M Selecting the input signal

Configuration block *M determines the input circuitry (input signal). The following inputs can be determined:

0	Pt 100	Version 1	-100 to 400 °C	
		Version 2	-30.0 to 150.0 °C	
1	4 (0) to 20 mA	}	Range selection under *M, decimal point, see *P	
2	0 (2) to 10 V			
3	} Thermocouples (with ref. junction module)	NiCr-Ni (K)	50 to +1200 °C	
4		Pt10Rh-Pt (S)	50 to +1700 °C	
5		Fe-CuNi (L)	50 to + 800 °C	
6		Cu-CuNi (U)	50 to + 600 °C	



*T Unit of temperature

0 °C (° Celsius)

1 °F (° Fahrenheit)



*R Range of current or voltage signal for X

0 0 to 20 mA or 0 to 10 V, depending on selection of *M (1 or 2)

1 4 to 20 mA or 2 to 10 V, depending on selection of *M (1 or 2)
(ignored for Pt 100 or thermocouple)



W* Range of current or voltage signal for WE

- | | | |
|---|-------------------------|---|
| 0 | 0 to 20 mA or 0 to 10 V | Depending on jumper WE |
| 1 | 4 to 20 mA or 2 to 10 V | Depending on jumper WE
(mA is factory default) |



Y* Range of current or voltage signal for Y and AA

- | | Y (depending on jumper Y)
(mA is factory default) | AA (depending on jumper AA)
(mA is factory default) |
|---|--|--|
| 0 | -20 to 20 mA or -10 to 10 V | 0 to 20 mA or 0 to 10 V |
| 1 | 4 to 20 mA or 2 to 10 V | 0 to 20 mA or 0 to 10 V |
| 2 | -20 to 20 mA or -10 to 10 V | 4 to 20 mA or 2 to 10 V |
| 3 | 4 to 20 mA or 2 to 10 V | 4 to 20 mA or 2 to 10 V |



DI Selecting the input circuitry of the derivative-action component

The input variable for the derivative-action component of the industrial controller can optionally be the controlled variable X or error XD.

- | | |
|---|----------|
| 0 | X input |
| 1 | Error XD |



WM Selecting the setpoint

An external setpoint WE can be applied either by actuating the WE/WI setpoint switchover key (9) or by applying an external signal (+24 V) at terminals 12 and 5 of the binary input. Configuration block WM determines the setpoint and the combination option.

- | | |
|---|--|
| 0 | WE input disabled |
| 1 | Addition of external WE and internal WI |
| 2 | Minimum selection between WE and WI |
| 3 | Maximum selection between WE and WI |
| 4 | Switchover using WE/WI key (9) |
| 5 | Switchover using WE/WI key (9) or by priority of the external signal +24 V |
| 6 | Switchover only by the externally issuing signal +24 V |
| 7 | Restart of the setpoint ramp beginning with applied X value |



YH Blocking the MANUAL/AUTOMATIC mode selector key (10)

- | | |
|---|-----------------------|
| 0 | Key function enabled |
| 1 | Key function disabled |



YM Selecting the controller output

- 0 Continuous output (see page 23)
- 1 Three-point stepping controller w. internal position feedback (see p. 26)
- 2 Three-point stepping controller with external position feedback (see p. 27)
- 3 Continuous controller output functions as recorder connection "X"
- 4 Three-point stepping controller (same as YM = 1) and recorder connection for controlled variable X at continuous controller output, valve position cannot be displayed.



YR External position feedback

The position feedback is also possible over a potentiometer 0 to (200 to 1000) Ω or over a standardized 4 to 20 mA signal.

- 0 0 to (200 to 1000) Ω
- 1 4 to 20 mA (with shunt resistance 549 Ω / 0.5 W / 1 % to terminals 1 and 2, see Fig. 5, page 9)



IM and 2M Signaling condition of the limit values

for the switching outputs Y1 and Y2



For YM = 1, 2 or 4, set IM and 2M to 0.

The values are determined by the parameters IR and 2R for the corresponding signaling condition. (Refer to section 5, page 23 for details).

Switches
when

- | | | | |
|---|--|---|--|
| 0 | Off | Switching output inactive | |
| 1 | X _{max} | X is above the limit | |
| 2 | X _{min} | X is below the limit | |
| 3 | XD _{min} | XD is below the limit | |
| 4 | XD _{max} | XD is above the limit | |
| 5 | XD _{min} and XD _{max} | XD is above or below the limit, tracking of controlled variable monitoring to the set point | |
| 6 | Y _{max} | Y is above the limit | <input type="checkbox"/> On-off/three-point control output |
| 7 | Y _{min} | Y is below the limit | <input type="checkbox"/> |
| 8 | Pulse-modulated control output, positive | | <input type="checkbox"/> See section 5.5, |
| 9 | Pulse-modulated control output, negative | | <input type="checkbox"/> page 29 |



S1 and S2 Switching outputs Y1 or Y2 as NO or NC contacts



- 0 NO make contact
- 1 NC break contact

**3M and 4M Signaling condition of the limit values**

for optional limit switches GW3 and GW4



The values are determined by the parameters 3R and 4R for the corresponding signaling condition.

Switches when	0	Off	Switching output inactive
	1	X_{\max}	X is above the limit
	2	X_{\min}	X is below the limit
	3	XD_{\min}	XD is below the limit
	4	XD_{\max}	XD is above the limit
	5	XD_{\min} and XD_{\max}	XD is above or below the limit
	6	Y_{\max}	Y is above the limit
	7	Y_{\min}	Y is below the limit

**53 and 54 Limit switches GW3 and GW4 as NO or NC contacts**

0 NO make contact



1 NC break contact

**TR Update cycle to refresh display of controlled variable**

0 Every 50 ms

1 Every 2 s

**FI Digital filter**

The digital filter FI is used to delay the analog inputs X and WE. Range of values 0 to 1999 s, disabled when set to 0

**KI Safety output value** Upon a sensor line break, restart value after power failure

Selectable between 0 and 109.9% of the manipulated variable output range.

If the signal range is violated (e.g. sensor line break/short-circuit), manipulated variable Y is automatically set to the predetermined value of KI.

In case of a power failure > approximately 100 ms, manipulated variable Y is used again from the value predetermined in KI. In the event of a power failure < approximately 100 ms, the manipulated variable Y remains at the last value output.

The controller starts in the last operating mode (manual or automatic) active before the power failure.



C1 and C2 code numbers

C1 Access to the PARAMETER level

C2 Access to the CONFIGURATION level

Both code numbers are factory set to 000. Their values can be changed in the range -1999 to +1999 as required. In the event that a code number has been forgotten, see notes under section Service code number.

Service code number

A higher-level code number for servicing is specified on page 38 of this manual, permitting the CONFIGURATION level to be opened despite the entered code numbers C1 and C2. To avoid unauthorized use, separate this number from page 38 (or scratch over to make fully illegible). The code numbers selected can then be read when configuration blocks C1 or C2 are called up.

Entry: Open CONFIGURATION level (see page 16); use the Service code number as the code.



50 Auto-tuning

0 Disabled, no auto-tuning

Only selectable when MANUAL/AUTOMATIC mode selector key (10) is set to MANUAL mode:

- 1 Ready for auto-tuning, tuned according to **setpoint** for loops with a delay > 10 s
- 2 Ready for auto-tuning, tuned according to **disturbance variable** for loops with a delay > 10 s

Auto-tuning enables the industrial controller to automatically tune itself to the characteristics of the control loop in the start-up phase and to calculate the "ideal" control parameters. The appropriate tuning is to be determined by selecting 1 or 2. For control loops which are critical and extremely fast and for which the control valve must not be abruptly adjusted, select 0 in order to disable the tuning facility (see also section 7.2, page 38).



TS Setpoint ramp



A setpoint ramp alters the setpoint at a constant speed. Configuration block TS determines the time for completing the entire setpoint range (XN to XE). The actual time (TS₁) to modify the setpoint is calculated by the industrial controller from this (see Fig. 6). This setpoint ramp is effective for every modification of the setpoint.

In this respect, note configuration block WM=7, see page 18. This setting causes the setpoint to perform an X-tracking (W = X) by adding the binary input. After switching back the input, the setpoint changes by the speed selected with TS until the desired value is obtained.

Range of values: TS is first indicated in the lower display field (2), and the value in the upper display field (1) is specified in seconds (0 to 1800 s). Afterwards, the lower display in (2) switches to TM, and the time is displayed in minutes (30 to 500 min).

To disable, set the parameter to 0.




SN Station address

- 0 Off (disabled)
- 1 to 245



BR Baud rate (selecting data transmission speed)

- 0 4800 bits/s
- 1 9600 bits/s



- XN Lower measuring range value
- XE Upper measuring range value
- W Setpoint
- W1 Old setpoint value
- W2 New setpoint value
- TS Time set for setpoint ramp (TS)
- TS₁ Calculated actual time for changing the set points W1 and W2

Fig. 6 · Setpoint ramp

5 Standard controller outputs

The standard version of the TROVIS 6497 Industrial Controller has one continuous output. Two switching outputs Y1 and Y2 are additionally available. These outputs can be configured as limit switches or on-off/three-step control outputs.

5.1 Continuous-action controller

Configuration block $YM = 0$ configures TROVIS 6497 as a continuous-action controller. Depending how the jumper Y is selected (see Fig. 3 on page 7), either a continuous mA or V signal is applied at terminals 1 and 2.

5.2 Switching outputs Y1 and Y2

Configuration blocks YM and $1M/2M$ determine the functions of switching outputs Y1 and Y2.





Fig. 7 · Switching outputs Y1 and Y2

5.2.1 Limit switches

TROVIS 6497 provides four limit switches (switching outputs Y1 and Y2 and two optional limit switches GW3 and GW4).

A limit switch monitors a variable to ensure that a minimum or maximum value (limit value) is maintained. Configuration blocks $1M$, $2M$, $3M$ and $4M$ (signaling condition of limit value) determine which variable is to be monitored for exceeding in either direction. Parameters $1R$, $2R$, $3R$ and $4R$ determine the limit value for the corresponding variable. Moreover, a hysteresis value (on-off differential) must be specified for each limit switch by means of parameters $1H$, $2H$, $3H$ and $4H$.

This hysteresis is the differential gap between the on-off state of the limit switch. When exceeded in either direction, the hysteresis acts in the opposite direction of the monitored variables (see Fig. 8).



Switching outputs Y1 and Y2 can be used as limit switches when configuration block $\gamma M = 0$. The signaling conditions of the limit values are assigned as follows:

$1M/2M/3M/4M = 0$	Disabled limit switch
$=$	Maximum/minimum absolute value of the controlled variable
$= 3/4$	Minimum/maximum absolute value of the error percentage
$= 5$	Minimum and maximum absolute value of the error percentage (with XD_{min} , limit values set under $1A/2A/3A/4A$ are negative)
$= 6/7$	Absolute value of the manipulated variable

Configuration blocks to be set:

$1M/2M$	$= 1$ to 7	Y1/Y2 as limit switch (only when $\gamma M = 0$, otherwise 0)
$3M/4M$	$= 1$ to 7	Optional limit switch GW3/GW4

Parameters to be entered:

$1A/2A$	$=$ Limit value	For Y1/Y2 (only when $\gamma M = 0$, otherwise 0)
$1H/2H$	$=$ Hysteresis	For Y1/Y2 (only when $\gamma M = 0$, otherwise 0)
$3A/4A$	$=$ Limit value	For GW3/GW4
$3H/4H$	$=$ Hysteresis	For GW3/GW4

5.2.2 On-off/three-step control output

Configuration blocks $\gamma M = 0$ and $1M = 6$ or 7 configure the on-off control output, which corresponds to monitoring a limit value for overcrossing by manipulated variable Y . Parameter $1A$ determines the limit value for the switching point; $1H$ determines the hysteresis as an absolute value of the manipulated variable Y .

Configuration blocks $\gamma M = 0$, $1M = 6$ and $2M = 7$ configure the three-step control output. Parameters $1A$ and $2A$ determine limit value for the switching point; $1H$ and $2H$ determine the hysteresis as an absolute value of the manipulated variable Y . Ensure that the difference between the upper and lower switching point is larger than the sum of the respective differential values: $1A - 2A \geq 1H + 2H$

When selecting the on-off or three-step control output, it is recommended to choose a P or PD algorithm for the process control application (set KP , TV , KD). The operating point $Y0$ and the minimum/maximum control manipulated variable limits (YL and YH) are to be selected in such a way that the outputs are always able to be switched on or off.

Limit switches GW3 and GW4 (also Y2 with on-off control output) can be further assigned to any signaling condition of the limit value.

Configuration blocks $51/2/3/4$ are used to configure switching outputs Y1 and Y2 and limit switches GW3 and GW4 as: 1) NO make contact ($51/52/53/54 = 0$); i.e., the relay closes when the signaling condition is satisfied or 2) NC break contact ($51/52/53/54 = 1$); i.e., the relay opens when the signaling condition is satisfied.

Configuration blocks to be set:

γM	= 0	
$1M$	= 6 or 7	(On-off controller)
$2/3/4M$	= 0 to 7	
$1M$	= 6 or 7	(Three-point controller)
$2M$	= 7 or 6	
$3/4M$	= 0 to 7	

Parameters to be set:

$1A/2A$	= Switching point
$1H/2H$	= Hysteresis




Fig. 9 · Three-point control output

5.3 Three-point stepping controller with internal position feedback

The three-point stepping controller with internal position feedback is selected with configuration block $\gamma M = 1$. Switching outputs Y1 and Y2 form the three-step output and are no longer available as limit switches. $1M$ and $2M$ are to be set to zero.

The operating time and effective ON time of the actuator are used to calculate the position of the final control element. The operating time of the actuator is specified by means of parameter $T I$. This value can be found in the actuator's technical description. In this output circuitry, it must have the same value to enable opening and closing of the final control element. The range of values for the manipulated variable cannot be limited. The parameters of the manipulated variable limits γL and γH are to be set to the minimum and maximum value.

External position feedback is not required for the control algorithm. However, the position of the final control element can be indicated in the lower display field to monitor the control valve. For this purpose, the position feedback signal must be determined using configuration block γP . When a potentiometer is connected, it must be calibrated (see section 5.3.1). If the position of the final control element is not to be displayed, see notes in section 5.3.1.

Parameter $1H$ specifies the hysteresis as a percentage of the manipulated variable Y and must not be larger than the product of $2 * T Z$. Parameter $T Z$ (dead band) defines the range from the current operating point to the respective switching point and is to be specified as a percentage of manipulated variable range. To obtain the value for the variable commonly defined as dead time (from negative switching point to positive switching point), $T Z$ must be doubled.

The industrial controller must be configured as a PI controller in order for it to perform the required three-point stepping characteristic. When this requirement is met, it operates as a quasi-continuous controller.

In MANUAL mode, a modification of γ directly affects the three-step output.

Configuration blocks to be set:

γM	= 1
$1/2M$	= 0

Parameters to be set:

$T I$	= Operating time of the actuator, e.g. 120 s
$1H$	= Hysteresis in %, e.g. 2.8 %
$T Z$	= Dead band % of the manipulated variable range, e.g. 3 %




Fig. 10 · Three-point stepping controller with internal position feedback

5.3.1 Calibrating the potentiometer

After connecting a potentiometer for the position feedback, it must be calibrated. The potentiometer must be calibrated prior to start-up! Please note that the industrial control automatically calibrates the span; zero, however, is already fixed.

Calibrate the potentiometer as follows:

1. Set the jumper Y to the mA position (see Fig. 3, page 73).
2. Set the potentiometer to the maximum value (200 to 1000 Ω)
3. Open the CONFIGURATION level (see page 16).
4. Select the configuration block γM using the cursor keys.
5. Press the ENTER key.
6. Depending on the output, select $\gamma M = 1$ or 2 using the cursor keys.
7. Press the ENTER key.
8. Press the MANUAL/AUTOMATIC mode selector key. CAL appears in the upper display field while the calibration is being performed. The calibration is finished when CAL disappears. The position feedback message is indicated in the lower display field.

Note!

If position feedback is not wanted for $\gamma M = 1$, the lower display field can be set to 00 . To achieve this, perform the calibration described above using "open" terminals. Subsequently, lay the jumper between terminal 1 and 2.

Optionally, select $\gamma M = 4$. After calibration with "open" terminals and laying the jumper (see above), 00 appears on the display instead of x . In this configuration, a recorder can be connected to log the controlled variable X.

5.4 Three-point stepping controller with external position feedback

Select this output using configuration block $\gamma M = 2$. The position of the final control element operated is transmitted as a feedback signal by means of a potentiometer (0 to (200 to 1000) Ω) or a direct current signal (4 to 20 mA) with shunt over the input of the external feedback YR (terminals 1 and 2). The maximum permissible current consumption of the potentiometer must be observed. The measuring current on connecting a 1-k Ω potentiometer is approx. 2.7 mA (approx. 13 mA with a 200- Ω potentiometer).

The manipulated variable can be limited as required.

Actuators with different transit times to open and close the valve are supported. Parameters $T 1$ and $T 2$ specify the period (not the transit time!) in the positive and negative direction of the actuator. An appropriately selected period offers a suitable compromise between the low residual ripple of the controlled variable (high switching frequency; i.e., cycle time selected to a low value) and a high operating life of the final control element (low switching frequency; i.e., period selected to a high value).

Parameters $1H$ and $2H$ determine the minimum pulse duration as a percentage of the corresponding period ($T 1$ and $T 2$). The value of the minimum pulse duration is to be selected in such a way that the connected actuators or contactors can just begin to switch.

The transfer coefficients $1R$ and $2R$ specify the inclination of the duty factor T_{Ein}/TP (T_{Ein} = ON time, TP = period ($T1$ or $T2$)). This allows the difference to be calculated when the duty factor is one (manipulated variable calculated by the industrial controller minus the feedback position of the final control element); i.e., the controller releases a continuous signal. The ON time is calculated by the following equation:

$$T_{Ein} = (Y - YR) \cdot A \cdot TP, \text{ whereby for } T_{Ein} > TP \text{ applies: } T_{Ein} = TP; A = 1R \text{ or } 2R$$

Parameter TZ (dead band) defines the range extending from the current operating point to the respective switching point and is to be specified as a percentage of the manipulated variable range. To obtain the value for the variable commonly defined for dead band (from negative switching point to positive switching point), double TZ .

In MANUAL mode, a modification of γ does not directly affect the three-step output, rather the input of the positioner integrated in the industrial controller. The duty cycle is shifted by changing the positioner's error (deviation). The industrial controller is pulsed according to the new duty cycle.

Configuration blocks to be set:

γM	= 2
$1/2M$	= 0
γR	= 0 or 1 (Selection of external feedback signal)





Fig. 11 · Three-point stepping controller with external position feedback

Parameters to be set:

$T1$	= Period in positive operating direction, e.g. 20 s
$T2$	= Period in negative operating direction, e.g. 20 s
$1H$	= Minimum pulse duration in positive operating direction in % of $T1$, e.g. 10 %
$2H$	= Minimum pulse duration in negative operating direction in % of $T2$, e.g. 10 %
$1R$	= Gain (transfer coefficient) in positive operating direction, e.g. 15
$2R$	= Gain (transfer coefficient) in negative operating direction, e.g. 15
TZ	= Dead band in % of the manipulated variable range, e.g. 3 %

5.5 Pulse-modulated control outputs

The pulse-modulated control output consists of a switching output, its ON time T_{Ein} being directly proportional to the internal manipulated variable Y in relation to the selected period $T1$.

5.5.1 On-off pulse-modulated outputs

This switching output is configured for $Y1$ by means of configuration block $1M = 8$ or 9 , where $1M = 8$ configures an on-off control output with positive operating direction, $1M = 9$ with a negative operating direction. Configure $Y2$ equivalent to $2M$.

The dead band TZ indicates at which percentage of the manipulated variable Y the output begins to switch. This corresponds to the minimum pulse duration as a percentage of the period.

Configuration blocks to be set:

YM	= 0
$1M/2M$	= 8 or 9 (On-off output with positive or negative operating direction)

Parameters to be set:

$T1$	= Period (cycle time), e.g. 20 s
TZ	= Minimum pulse duration as a percentage of the period $T1$, e.g. 10 %

5.5.2 Dual on-off pulse-modulated outputs

This configuration is selected with $IM = 8$ and $ZM = 9$. Both switching outputs Y1 and Y2 are pulse-modulated and form two on-off control outputs for the positive and negative internal manipulated variable Y.

Parameter TZ indicates at which percentage of the manipulated variable Y the output begins to switch. This corresponds to the minimum pulse duration as a percentage of the period.

Configuration blocks to be set:

IM	= 8	(Pulse-modulated positive)
ZM	= 9	(Pulse-modulated negative)

Parameters to be set:

TI	= Period (cycle time), e.g. 20 s
TZ	= Minimum pulse duration as a percentage of the period TI , e.g. 3 %

5.5.3 Dual on-off pulse-modulated outputs in split-range (positive or negative)

This selection is used to operate switching outputs Y1 and Y2 in split range. Parameter TZ determines the split-range point in reference to internal manipulated variable Y; parameter TZ no longer specifies the minimum pulse duration.

Parameters $S1 / S2$ determine the operating direction of the split-range outputs. This is positive for $S1 / S2 = 0$, otherwise negative.

Configuration blocks to be set:

IM	= 8	(Split-range positive) or	9	(Split-range negative)
ZM	= 8	(Split-range positive) or	9	(Split-range negative)

Parameters to be set:

TI	= Period (cycle time), e.g. 20 s
TZ	= Split-range point

6 Serial interface

6.1 Description

The TROVIS 6497 Industrial Controller is able to communicate with a control station via the serial interface. A complete automation system for process control can be constructed by means of software capable of process visualization and communication. Here, the commonly used Modbus communications protocol is implemented as the communication standard. The hardware relating to the serial interface satisfies the requirement of the RS-485 interface (RS = Recommended Standard according to EIA).

If the controller is intended to terminate the bus, five soldering jumpers "LB1" to "LB5" must be connected on the components (soldering) side of the interface board (see Fig. 2, page 6).




Fig. 13 · Process control system with TROVIS 6497 Industrial Controllers

6.2 Technical data

Physical interface	RS-485
Communications protocol	Modbus RTU 584
Data transmission	Asynchronous, half-duplex (four-wire)
Character format	RTU (8 bits) 1 start bit, 8 data bits, 1 stop bit
Baud rate	4800 or 9600 bits/second
Number of addressable stations	246
Transmittable data	Configuration, parameters, operating state, process variables

6.3 Operation

6.3.1 Setting the station addresses

An unassigned station address is defined in the industrial controller to identify a subscriber (user) in the communication network. Configuration block S_N configures a station address in the CONFIGURATION level. The factory default is set to 0 (= off). After a station address has been configured, configuration block S_N cannot be reset to 0 any more.

6.3.2 Allocating the value register

Value registers contain values of analog variables; e.g., controlled variable, setpoint, etc. Value registers 1, 2, 3, 4, 6, 7, 8, 11, 55, 56, 57 can only be read by the control station if they are denoted by an R (Read). The remaining value registers can be both read and written by the control station (R/W = Read/Write).

6.3.3 Allocating the status register

Status registers contain binary information such as fault alarms, relay states or operating messages.

Status registers 1 to 4 and 15, 16 can only be read by the control station (read only). Status registers 5 to 14 can be both read and written (R/W).

6.3.4 Modbus protocol

The Modbus communications protocol defines the communication standard implemented between the industrial controller and the control station. In this communication scheme, the control station acts as the "master", the industrial controller as the "slave". Therefore, the industrial controller may only respond to control station requests.

6.3.5 Function code 01 (Read Coil Status)

This function code reads status registers (see table on page 34) in the industrial controller and transmits these to the control station.

6.3.6 Function code 05 (Force Single Coil)

A certain status register is modified in the industrial controller by the control station with this function code (see table on page 34).

6.3.7 Function code 03 (Read Holding Register)

This function code allows status registers (see table on page 33) to be read from the industrial controller and, after conversion in the numeric format, displayed on the PC.

6.3.8 Function code 06 (Preset Single Register)

With this function code, the control station reads and modifies a certain value register in the industrial controller (see table on page 33).

6.3.9 Error messages according to Modbus

The communication interface responds with an error message upon illegal operations. These types of illegal actions include, for example, attempt to read more than 58 value registers or attempt to write read-only registers containing status information or values.

6.4 Value registers (holding registers)

No.	Name	Access	Register range	Div.	Description
1	ID	R	6497	0	Controller ID
2	VN	R	1001 to 1002	1 ¹⁾	Version: Software/Pt 100
3	X	R	-1999 to 1999	2)	Controlled variable
4	WE	R	-1999 to 1999	2)	External setpoint (ext. reference variable)
5			0		Reserved
6	YSTEEL	R	-10 to 110	0	Position feedback
7	XD	R	-1999 to 1999	2)	Error
8	Y	R	-1099 to 1099	1	Manipulated variable PID
9	YHAND	R/W ⁴⁾	-1999 to 1999	1	Manipulated variable output
10	WI	R/W ⁴⁾	-1999 to 1999	2)	Internal setpoint (int. reference variable)
11	SN	R	1 to 246	0	Station address
12	KP	R/W ⁴⁾	0 to 1999	1	Proportional-action coefficient
13	TN	R/W ⁴⁾	0 to 1999	0	Reset time
14	TV	R/W ⁴⁾	0 to 1999	0	Rate time
15	KD	R/W ⁴⁾	0 to 10	0	Rate gain
16	WR	R/W ⁴⁾	0 or 1	0	Reverse error
17	YMIN	R/W ⁴⁾	-1099 to 1099	1	Minimum manipulated variable limit
18	YMAX	R/W ⁴⁾	-1099 to 1099	1	Maximum manipulated variable limit
19	Y0	R/W ⁴⁾	-1099 to 1099	1	Operating point
20	1A	R/W ⁴⁾	-1999 to 1999	3)	Limit value/switching output Y1
21	1H	R/W ⁴⁾	0 to 1999	3)	Hysteresis Y1
22	2A	R/W ⁴⁾	-1999 to 1999	3)	Limit value/switching output Y2
23	2H	R/W ⁴⁾	0 to 1999	3)	Hysteresis Y2
24	T1	R/W ⁴⁾	0 to 1999	0	Switching time/period (cycle time) +
25	T2	R/W ⁴⁾	0 to 1999	0	Switching time/period (cycle time) -
26	TZ	R/W ⁴⁾	0 to 1099	1	Dead zone
27	3A	R/W ⁴⁾	-1999 to 1999	3)	Limit value of GW3
28	3H	R/W ⁴⁾	0 to 1099	3)	Hysteresis of GW3
29	4A	R/W ⁴⁾	-1999 to 1999	3)	Limit value of GW4
30	4H	R/W ⁴⁾	0 to 1099	3)	Hysteresis of GW4
31	XN	R/W ⁴⁾	-1999 to 1999	2)	Minimum controlled variable limit
32	XE	R/W ⁴⁾	-1999 to 1999	2)	Maximum controlled variable limit
33	X _d	R/W ⁴⁾	0 to 3	0	Decimal point
34	XM	R/W ⁴⁾	0 to 6	0	Input signal
35	XT	R/W ⁴⁾	0 or 1	0	Unit of temperature
36	X*	R/W ⁴⁾	0 or 1	0	Range selection for X
37	W*	R/W ⁴⁾	0 or 1	0	Range selection for W
38	Y*	R/W ⁴⁾	0 to 3	0	Range selection for Y
39	DI	R/W ⁴⁾	0 or 1	0	Assignment of derivative-action component
40	WM	R/W ⁴⁾	0 to 7	0	Selection of setpoint
41	YH	R/W ⁴⁾	0 or 1	0	Blocking the MANUAL/AUTOMATIC key
42	YM	R/W ⁴⁾	0 to 4	0	Selection of controller output

No.	Name	Access	Register range	Div.	Description
43	YR	R/W ⁴⁾	0 or 1	0	External position feedback Ω /mA
44	1M	R/W ⁴⁾	0 to 9	0	Signaling condition of GW1
45	2M	R/W ⁴⁾	0 to 9	0	Signaling condition of GW2
46	S1	R/W ⁴⁾	0 or 1	0	NC contact /NO contact of Y1 (GW1)
47	S2	R/W ⁴⁾	0 or 1	0	NC contact /NO contact of Y2 (GW2)
48	3M	R/W ⁴⁾	0 to 7	0	Signaling condition of GW3
49	4M	R/W ⁴⁾	0 to 7	0	Signaling condition of GW4
50	S3	R/W ⁴⁾	0 or 1	0	NC contact /NO contact of GW3
51	S4	R/W ⁴⁾	0 or 1	0	NC contact /NO contact of GW4
52	TA	R/W ⁴⁾	0 or 1	0	Update cycle to refresh display (1)
53	FI	R/W ⁴⁾	0 to 1999	0	Digital filter for X and WE
54	K1	R/W ⁴⁾	0 to 1099	1	Safety output value
55	C1	R	-1999 to 1999	0	PARAMETER level code number
56	C2	R	-1999 to 1999	0	CONFIGURATION level code number
57	SO	R	0 to 2	0	Auto-tuning
58	TS	R/W ⁴⁾	0 to 30000	0	Setpoint ramp

1) Consisting of software version, e.g. 1.00 and Pt 100 version 1 or 2: 100.1 or 100.2 respectively

2) Varies depending on how input signal XM is configured:

- No decimal point for XM = 3, 4, 5, 6 and XM = 0 version 1

- One decimal point for XM = 0 version 2

- Decimal point for 0 to 3 decimal point(s) depending on configuration block X, for XM = 1, 2

3) Depending on XM, YM and assignments 1M to 4M

4) Data are written in EEPROM which is restricted to approx. 100,000 write cycles. Therefore, do not always write in it automatically.

6.5 Status register

No.	Access	Description
1	R	Collective fault (internal device fault)
2	R	Safety output value K1 active ¹⁾
3	R	Enable parameterization
4	R	Enable configuration
5	R/W	Limit value/switching output Y1
6	R/W	Limit value/switching output Y2
7	R/W	Limit value of GW3
8	R/W	Limit value of GW4
9	R/W	Inhibit parameterization
10	R/W	Confirm parameterization
11	R/W	Inhibit configuration
12	R/W	Confirm configuration
13	R/W ²⁾	Switchover to MANUAL mode
14	R/W ²⁾	Switchover to external setpoint WE
15	R	Reserved
16	R	Reserved

1) The safety output value is set for an input signal fault. The alarm is only generated in automatic mode.

2) Data are written in EEPROM which is restricted to approx. 100,000 write cycles. Therefore, do not always write in it automatically.

7 Start-up

The configuration blocks and parameters must be determined after completing all electrical connections (see page 8), deciding what jumpers are needed (see page 7) and installing the industrial controller (see page 6).

Always take the characteristics of the control loop into account before putting the industrial controller into operation. Avoid potential risks by means of appropriate parameters.

Make note of the configured values after putting the controller into operation.

Note!

The industrial controller should first be configured, then enter the parameters and, finally, tune them.

Firmware version (EPROM version):

After switching on the mains power supply, the implemented firmware version of the industrial controller is shown in the upper display field. This version number is important when making inquiries.

Configure the industrial controller as following:

- **Open the CONFIGURATION level** (see page 16)
- Select the input signal $\ast M$
- Determine the measuring range of the input signal by means of $\ast N$ (start value) and $\ast E$ (end value)
- Select the control outputs with γM , $1M$, $2M$, γR ; see also section 5, beginning with page 23.
- Select the desired special functions such as digital filter $F I$, unit of temperature $\ast T$, signaling conditions of the limit value $\text{E} / 3 / 4M$ or safety output value $K I$
- **Open the PARAMETER level** (see page 13)
- Determine the operating direction by means of WR
- Limit the output signal by means of γL and γP
- Enter the parameters for the desired output; see also section 5, beginning with page 23
- Determine the desired limit values with $\text{E} / 3 / 4R$
- **Tune** the plant by entering the parameters: Proportional-action coefficient $K P$, reset time $T N$, rate time $T V$, and rate gain $K B$; see also section 7.1 and 7.2.

7.1 Tuning control parameters

The industrial controller must be tuned to the dynamic behavior of the loop using the parameters: Proportional-action coefficient K^P , reset time T^N and rate time T^V . This permits the controller to compensate for control deviations caused by disturbances by reducing these to zero or maintain them in very confined limits.

If you do not have previous experience in selecting values for the control loop, proceed as follows:

- Set the MANUAL/AUTOMATIC mode selector key (10) to MANUAL mode.
- Move the attached control valve to the CLOSED position; if applicable, via the cursor keys.
- After deciding which control mode is necessary, proceed further as instructed below.

P controller

- Specify control parameters proportional-action coefficient $K^P = 0.1$; reset time $T^N = 0$ and rate time $T^V = 0$ in the PARAMETER level.
- Enter the desired value of the setpoint in the OPERATING level. Then, modify the manipulated variable γ until the control valve slowly opens and the error $\% E$ is eliminated (becomes zero).
- Switch over to AUTOMATIC mode
- Increase the K^P value until the control loop tends to hunt.
- Reduce the K^P value until oscillation cannot be determined any more.
- Correct steady-state deviation by selecting the operating point γ_0 as follows: Read the current value of manipulated variable γ when the plant is in the steady state, and enter as value under parameter γ_0 .

Note!

A setpoint modification also means a change of the operating point γ_0 .

PI controller

- Specify control parameters proportional-action coefficient $K^P = 0.1$; reset time $T^N = 1999$ (maximum) and rate time $T^V = 0$ in the PARAMETER level.
- Enter the value of the desired setpoint in the OPERATING level. Then, modify the manipulated variable γ until the control valve slowly opens and the error $\% E$ is eliminated (becomes zero).
- Switchover to AUTOMATIC mode
- Increase the K^P value until the control loop tends to hunt.
- Slightly decrease the K^P value until oscillation cannot be determined any more.
- Reduce the T^N value until the control loop tends to hunt.
- Slightly increase the T^N value until oscillation cannot be determined any more.

PD controller

- Specify control parameters proportional-action coefficient $K^P = 0.1$; rate time $T^I = 0$ and reset time $T^N = 0$ in the PARAMETER level. Set the rate gain K^D in usual cases between a value of 5 and 10.
- Enter the value of the desired setpoint in the OPERATING level. Then, modify the manipulated variable y until the control valve slowly opens and the error w is eliminated (becomes zero).
- Increase the K^P value until the control loop tends to hunt.
- Set rate time T^I to 1 seconds and increase until oscillation cannot be determined any more.
- Increase the K^P value until the control loop tends to hunt again.
- Decrease the T^I value until oscillation cannot be determined any more.
- Proceed in the same manner several times until the oscillations cannot be suppressed any more.
Slightly decrease the K^P value and T^I value until the control loop stabilizes itself again.
- Eliminate steady-state deviation by adjusting the operating point y_0 as follows: Read the current value of the manipulated variable y when the plant is in the steady state, and enter as value for parameter y_0 .

Note!

A setpoint modification also means a change of the operating point y_0 .

PID controller

- Specify control parameters proportional-action coefficient $K^P = 0.1$, rate time $T^I = 1999$ and reset time $T^N = 0$ in the PARAMETER level. Set the rate gain K^D in usual cases between a value of 5 and 10.
- Enter the value of the desired setpoint in the OPERATING level. Then, modify the manipulated variable y until the control valve slowly opens and the error w is eliminated (becomes zero).
- Increase the K^P value until the control loop tends to hunt.
- Set rate time T^I to 1 seconds and increase until oscillation cannot be determined any more.
- Increase the K^P value until the control loop tends to hunt again.
- Increase the T^I value until oscillation cannot be determined any more.
- Proceed in the same manner several times until the oscillations cannot be suppressed any more.
Slightly decrease the K^P value and T^I value until the control loop stabilizes itself again.
- Reduce the T^N value slightly until the control loop tends to hunt again and increase it again until no oscillations cannot be determined any more.

7.2 Auto-tuning

Auto-tuning is a special feature of the industrial controller which, in the start-up phase, effectively determines the characteristics of the control loop and calculates the optimum control parameters.

This function should only be used on control loops which are not critically fast and have short dead bands. If auto-tuning is used, the tuning procedures described in section 7.1 can be omitted.

The automatically determined control parameters should be checked for applicability before switching to AUTOMATIC mode.

If the industrial controller indicates an unsatisfactory behavior when being operated, the calculated control parameters must be manually modified.

Proceed as follows to automatically determine the control parameters:

1. Prerequisites:

The control loop must be stable and in the steady state for at least 5 minutes; i.e., the error $\%E$ must not have changed.

A PI algorithm is to be specified for the industrial controller (rate gain $K_D = 0$). If a PID algorithm is desired, set the parameter to ($K_D = 1$).

The controller runs in the OPERATING level (normal operation); controlled variable X and manipulated variable Y are displayed.

2. Switch the MANUAL/AUTOMATIC mode selector key to MANUAL mode (LED illuminates in the key).

3. Open the CONFIGURATION level (see page 16).

4. Select configuration block $S0$ using the cursor keys

5. Set the desired tuning mode $S0 = 1$ or 2 , and store using the ENTER key (8).

6. Press the operating key (7). (The industrial controller returns to the OPERATING level.)

7. Specify the value for the setpoint (internal WI or external WE) for which a positive error $\%E$ of at least 20 % of the measuring range is set. Check at XD.

8. Press the MANUAL/AUTOMATIC mode selector key (10) in order to switch to AUTOMATIC mode. The control parameters are calculated and stored against power failure as long as the yellow LED flashes in the key. After the LED goes out, the controller operates in AUTOMATIC mode.

If the LED does not go out, parameters cannot be determined in this manner. Abort the process by pressing the MANUAL/AUTOMATIC mode selector key.

Service code number

1732


8 Check list

Device:	Plant:	Process designation:	Date:
---------	--------	----------------------	-------

Select	Designation	Range of values	Default setting	Start-up values, modifications		
OPERATING level						
∞	Controlled variable	Depending on sensor	–			
∞ _B	Error	–	–			
∞I	Internal setpoint (ref. variable)	∞N to ∞E	0			
∞E	External setpoint (ref. variable)		–			
γ	Manipulated variable	γ _L to γ _P	–			
PARAMETER level						
K _P	Proportional-action coefficient	0.1 to 199.9	1.0			
T _N	Reset time	1 to 1999	10			
T _V	Rate time	1 to 1999	0 (Off)			
K _B	Rate gain	1 to 10	0 (Off)			
∞R	Operating direction	0 or 1	1 (<=>)			
γ _L	Min. manipulated variable limit	–109.9 to ∞ _P	0			
γ _P	Max. manipulated variable limit	γ _L to 109.9	100			
γ _B	Operating point	–109.9 to 109.9 %	0			
I _R	Limit value of Y1	Depending on I _M	0			
	Transfer coefficient +	0.0 to 100.0	0.0			
I _H	Hysteresis of Y1	Depending on I _M	0			
	Minimum pulse duration	0.0 to 100.0 %	0.0			
∑ _R	Limit value of Y2	Depending on ∑ _M	0			
	Transfer coefficient–	0.0 to 100.0	0.0			
∑ _H	Hysteresis of Y2	Depending on ∑ _M	0			
	Minimum pulse duration	0.0 to 100.0 %	0			
T _I	Period (cycle time) +	0 to 1999 s	10			
T _∑	Period (cycle time) –	0 to 1999 s	10			
T _∑	Dead band	0 to 109.9 %	2.0			
Options						
∑ _R	Limit value of GW3	Depending on ∑ _M	0			
∑ _H	Hysteresis of GW3	Depending on ∑ _M	0			
∑ _R	Limit value of GW4	Depending on ∑ _M	0			
∑ _H	Hysteresis of GW4	Depending on ∑ _M	0			

Select	Designation	Range of values	Default setting	Start-up values, modifications		
CONFIGURATION level						
XN	Min. measuring range limit X	-1999 to XE	0			
XE	Max. measuring range limit X	XN to 1999	100.0			
X,	Decimal place	1.000 to 1000	100.0			
XM	Selection of input signal	0 to 6	0 (Pt 100)			
XT	Unit of temperature	0 or 1	0			
X*	Range of mA or V signal	0 or 1	0 (mA)			
W*		0 or 1	0 (mA)			
Y*		0 to 3	0 (mA)			
BI	Derivative-action component	0 or 1	0			
WM	Selection of setpoint	0 to 7	0			
YH	MANUAL/AUTOMATIC key	0 or 1	0			
YM	Selection of controller output	0 to 4	0			
YR	External position feedback	0 or 1	0			
1M	Signaling condition of limit value	0 to 9	0			
2M		0 to 9	0			
51	NO contact or NC contact	0 or 1	0			
52		0 or 1	0			
Options for versions with limit switches GW3 and GW4						
3M	Signaling condition of limit value	0 to 7	0			
4M		0 to 7	0			
53	NO contact or NC contact	0 or 1	0			
54		0 or 1	0			
Options for all versions						
TR	Update cycle to refresh display of controlled variable	0 or 1	0			
FI	Digital filter	0 to 1999 s	1			
K1	Safety output value	0 to 109.9 %	0			
E1	PARAMETER level code number	-1999 to 1999	0			
E2	CONFIGURATION level code	-1999 to 1999	0			
SD	Auto-tuning	0 to 2	0			
TS / TM	Setpoint ramps	1 s to 500 min	0			
Options for version with interface						
SN	Station address	0 to 246	0			
BR	Baud rate	0 or 1	0			

9 Control panel



- 1 Display of controlled variable
- 2 Display of manipulated variable
- 3 Display of error
- 4 Display of switching output
- 5 Label for engineering unit

- 6 Cursor keys
- 7 Operating key
- 8 Enter key
- 9 WE/WI setpoint switchover key
- 10 MANUAL/AUTOMATIC mode selector key



SAMSON AG · MESS- UND REGELTECHNIK
Weismüllerstraße 3 · 60314 Frankfurt am Main · Germany
Phone: +49 69 4009-0 · Fax: +49 69 4009-1507
Internet: <http://www.samson.de>

EB 6497 EN

S/Z 2008-10