# **Temperature Sensor**

# Types 5201 to 5261

with NTC Resistors



## **Application**

Sensors for measuring temperatures in heating, ventilation and air-conditioning systems. Versions with NTC (Negative Temperature Coefficient) resistors.

Basic values are according to the specified technical data.



### Temperature sensors with NTC resistor

Temperature sensors with NTC resistor																
Screw-in sensor		•	•	•	•	•	•	•								
Duct sensor									•	•	•					
Strap-on sensor												•				
Outdoor sensor													•			
Room sensor														•	•	<b>●</b> 1)
Measuring range	−20 to 50 °C		•						•				•	•		
	0 to 40 °C							•		•					•	•
	20 to 120 °C	•		•	•	•	•				•	•				
NTC resistor $\Omega$		2970 to 550	3030 to 609		2970	o 550		2970 to 750	3030 to 609	2970 to 750	2970 to 550	2970 to 550	3030 to 609	3030 to 609	2970 to 750	2970 to 750
Sensor length	l	80	160	160	250	160	250	160	300	300	300	_	ı	ı	-	1
Sensor shaft (	G 1/2	Brass	Brass	Brass	Brass	1.4571	1.4571	1.4571	Brass n-p	Brass n-p	Brass n-p	-	-	-	-	1
Nominal PN pressure		16 2					40		_							
Perm. medium temp.	°C	-10 -35 to to -10 to 130 130 85					-	35 to 85 -10 to 130 -35 to 85								
Perm. ambient °C temp.		-20 to 70							-20 to 70			-10 to 130	-35 to 85			
Degree of protection	IP	54							41			54	54 20			
Туре		5201 -3	5201 -01	5201 -11	5201 -12	5201 -13	5201 -14	5201 -33	5210	5213	5211	5261 -2	5220 -1	5250	5253	5253 S
Style																<b>®</b> .
Preferable application		Heating flow pipes	Swimming pools	Heating flow pipes	Water heaters	Heating flow pipes	Water heaters	Swimming pools		Mixed air, supply air and exhaust air	ı	Heating flow pipes	Exterior walls	Living and working rooms		

<sup>1)</sup> With set point adjuster 0 to 1000 Ohm

#### Note


For temperature sensors containing a NTC resistor, line balancing is not required. Should the connecting lines between sensor and controller be longer than 100 m, line cross-section should be min.  $1.5 \, \mathrm{mm}^2$ .

The connecting lines between temperature sensor and controller are to be installed separated from the lines conducting system voltage.

### Ordering text

Temperature Sensor with NTC Resistor Type ...

### Dimensions in mm and weights



Specifications subject to change without notice.

